
# Installation Instruction of 7/16 type Connector

( PLU010523 1/2" Cable)

Edition No. H/1

Please read the instruction carefully before installation. Any improper operation can result in badness influence and sequel.

Installation tools and material: Millimeter Scale Ruler, Electric Knife, Monkey Wrench, Flat File, Hair Brush and so on.




## 1) Structure of Connector: (Fig 1)

Parts of Connector: 1. Main shell body; 2. Cable Clip.


#### 2) Decorticate:

Size of cable to be decorticated should be strictly according to it indicated in Fig2, the end surface of inner conductor should be chamfered by small file of 1 × 45°. Smooth the processing surface and clean copper scraps on the kerf and bur on the inner conductor.



### 3) Install Cable Clip:

Set cable clip on cable, outer conductor should be longer than the plane of the clip 2.5mm,position as indicated in Fig 3.



## 4) Install Main Shell Body: (Fig 4)

Keeping cable clip stopped, tighten main shell body to cable clip. See fig 4.Assembling is finished.

